STEREO SYSTEM RACK

# SRC-402@ /442@

## KENWOOD

KENWOOD CORPORATION

### ASSEMBLY INSTRUCTIONS


©PRINTED IN U.S.A. B61-0520-00(K)(TCA)

#### IMPORTANT:

- Before operating your new KENWOOD product, read through this assem bly manual carefully to get the most out of it.
- · Save this assembly instructions.

#### Before Assembling

- Be sure to check that all parts are accounted for before disposing of the packing case.
- · A Phillips screwdriver and a mallet are required for assembling.
- · Be carefull not to damage the floor and rack.



#### Notes on Assembling

- During assembling, be sure to verify the numbers stamped on the boards.
- Mount the rear panel after assembling the side panel on the bottom shelf at a right angle.
- When mounting the top shelf and kick plate on the side panel, use glue for adhesive. Be sure to remove any excess glue before it dries.

#### **Handling Precautions**

- Tempered glass is used for the glass doors for providing sufficient strength.
  However, pay attention not to apply excessive force or to scratch the doors. Cracking or breaking of the glass may occur.
- When moving the cabinet, remove all the components from the rack before carrying the cabinet. Also do not grasp the top shelf when carrying.
- To allow head radiation from the components, leave a space of 4 inches between the cabinet and wall.
- Do not place the cabinet in a location subject to direct sunlight or near a heater, an air-conditioner, or a place with high humidity.

## IMPORTANT SAFEGUARDS

⚠ Caution : Read this page carefully to keep your safety.

Please read all of the safety and operating instructions before operating this unit. For bes' its, follow all warnings placed on the unit and adhere to the operating and use uctions. These safety and operating instructions should be retained for unit truther reference.


Suffocation — After taking the unit out of the polyethylene bag, be sure to dispose of the polyethylene bag out of the reach of children. Otherwise, they may play with the bag, which could cause hazard of suffocation.



 Water and moisture — Do not place a liquid container, such as a vase and water basin, on the unit. Also avoid installing the unit in a place subject to dampness.



 Heat — Do not install the unit near a source of heat, such as a heater, or under direct sunlight.



4. Impact — Avoid placing the unit on an unstable surface. Install it on a horizontal surface not subject to excessive dirt or vibrations.



 Modification — Do not attempt to open or modify the unit, for this could cause fire hazard or malfuriction.



6. Cleaning — Do not use thinner, benzine or alcohol. When cleaning the unit, wipe with a soft, dry cloth.




7. Abnormal smell — In the event the unit generates smoke or abnormal smell, immediately switch the power OFF and unplug the power cord. After this, please contact your dealer or nearest service station as soon as possible.









#### PARTS LIST MODEL SRC-402 © /442 © **ASSEMBLY INSTRUCTIONS** ASSEMBLED RACK Part No. Q.T.Y. Description Net weight: 47.4 lbs. (21.5 kg) SRC-402 © S0033 1 4 SRC-442 ® S0035 (A)- $\bigcirc$ S0034 8 (K) M0018 2 P0054 $\bigcirc$ Dimensions 1 P0011 Unit : inch (mm) 2 3 14-7/8" (378) 17-1/4" (438) 19-5/8" (498) $\mathbb{N}$ P0053 7-13/16" (198) 12-1/2" (318) 5-7/16\* (138) 4-1/8" (104) 8-13/16" (224) 4-1/8" (104) 0 G0067 STEP 1 P 9 W0092 **Q** G0012 1 (L) 👙 WOODGRAIN UP 4 B0015 1 M0026 STEP 2 1 M0027 $(J) \times 2$ $\bigcirc$ M0011 $\bigcirc$ 1 G0047 WOODGRAIN SURFACES DOWN AND FORWARD W G0205 Glass Door



## · ASSEMBLY INSTRUCTIONS



## STEP 7



i	MODEL:	: SRC-402 © /442 ©			-					
ı					PARTS I	IST				
1	ITEM	DESCRIPTON	QTY	PAR <sup>2</sup>		ITEM	DESCRIPTION	QTY	PART NO.	If any parts are MISS-
ŧ	-			SRC-402®	SRC-442®	L				ING or DAMAGED in
ł	Α	LEFT SIDE PANEL	1	XW0501	XW0514	M	MAGNET CATCH	1	P0011	this package, circle the
ı	В	BOTTOM BOARD	1	XW0400	XW0400	l N	SHELF PIN	4	P0053	item(s) needed on the parts list. Print your
ı	С	RIGHT SIDE PANEL	1	XW0500	XW0513	1 0	RUBBER SPACER	4	G0067	
١	D	KICK PLATE	1	XW0502	XW0515	P	WOOD DOWEL	9	W0092	name, address, and
J	Ε	TOP BOARD	1	XW0499	XW0512	l q	GLUE	1	G0012	phone number in the
1	F	BACK BOARD	1	XW0493 .	XW0493	R	SHELF PIN	4	B0015	area to the left and mail
ı	G	SHELF A	1	XW0398	XW0398	s	UPPER HINGE	1	M0026	to: TOCABIAMERICA, 9375 Custom House Plaza Road, Suite I
ı	н	SHELF B	1	XW0399	XW0399	Т	LOWER HINGE	1	M0027	
1	- 1	CONFIRMAT SCREW	4	S0033	S0035	U	CATCH PLATE	1	M0011	
ı	J	SCREW	8	S0034	S0034	i v	CATCH PLATE PAG	) i	G0047	San Ysidro, CA 92173.
1	K	ALLEN WRENCH	1	M0018	M0018	l w	GLASS DOOR	1	G0205	or call (619)-661-6136.
	L	HINGE INSERT	2	P0054	P0054	1			00200	Or Call (019)-001-0130.
1						•				